

iFi nano iDSD connect to Android: 3 Easy Steps.



Step 1: Which Android device do you have?

Please check the Appendix: “List of Android compatible Device” and “List of Android non-compatible Device”¹.

- If your device is not on the list, you may just have to try it out. Most new mid to high-end model Android phones from major manufactures do support USB Audio.
- If an older model is compatible, then a similar newer model will also usually be compatible even if it is not in the list.


Step 2: Add OTG Cable.



Note: OTG cable is slightly different from the normal USB cable (it has one extra connection inside the cable), normal USB cable will not work.

Step 3: Install USB Audio Player Pro.

USB Audio Recorder Pro will also work, but we recommend USB Audio Player Pro for its ease of use.



<https://play.google.com/store/apps/details?id=com.extreamsd.usbaudioplayerpro>

Done! You can now play music through the iFi nano iDSD from your Android device.

¹ <http://www.extreamsd.com/USBAudioRecorderPRO/>

Appendix: List of Android compatible devices.

Manufacturer	Model	Notes
Acer	Iconia Tab A200	Has a full-sized USB port next to a micro USB port
	Iconia Tab A210	
	Iconia Tab A500	Has a full-sized USB port next to a micro USB port
	Iconia A1-810	ONLY playback!
Archos	80 G9	
Asus	Memo 7"	Note that the HD version does NOT work!
	MemoPad ME172V	
	MemoPad 10.1	
	Padfone	
	Slider SL101	
	TF101	
	TF201	When using the USB port on the keyboard dock, noise is introduced
	TF300	When using the USB port on the keyboard dock, noise is introduced. Using an Asus USB adaptor directly on the tablet, all is fine.
	TF700	Try 'Airplane mode' when using the dock
	TF701T	Works fine, even with the dock
	Transformer Prime	
Atheros	8"	
Google/LG	Nexus 5	
Google	Nexus 7	May require a reboot with the audio device connected AND the language set to English-US (no kidding!). Google is said to solve this issue.
	Nexus 7 (2013)	May require a reboot with the audio device connected AND the language set to English-US (no kidding!). Google is said to solve this issue.
	Nexus 10	May require a reboot with the audio device connected AND the language set to English-US (no kidding!). Google is said to solve this issue.
HTC	One	Seems to work with Android 4.2.2
	One X	
Huawei	Ascend P6	
	Mate MT1-U06	
iconBit	Nettab NT-0801C	
iNew	6000	
Lenovo	B6000 / Yoga Tablet 8	
	IdeaTab S6000-F	Only when rooting and adding host permissions file?
LG	G2	
	G Pad 8.3	
	Optimus G	
Meizu	MX Quad	
Motorola	Moto G	
	Photon Q	
	Razr HD Maxx	
	Razr M XT905	Note that this is not the same as the Droid Razr M which does not work!
	Razr HD XT925	
	Xoom	
MPMan	Mid43c	
MSI	Primo 76	
Ritmix	RMD-1025	
Samsung	Note 2	
	Galaxy Camera EK-G100	
	Galaxy Nexus	Causes glitching with some audio devices
	Galaxy Note 1 I717	Note, only this special version of the Note 1 works!
	Galaxy Note 2	

	Galaxy Note 3	
	Galaxy Note 8	
	Galaxy Note 10.1	May need USB debugging turned on
	Galaxy Note 10.1 2013/2014 model	
	Galaxy R	
	Galaxy S3	
	Galaxy S4	Requires Android 4.3
	Galaxy S4 active	
	Galaxy Tab 1 7.7	
	Galaxy Tab 1 10.1	
	Galaxy Tab 3 8"	
Sony	Acro S	
	Tablet S	
	Xperia Active	
	Xperia Arc S	
	Xperia S	
	Xperia Sola	
	Xperia SP	
	Xperia SX	
	Xperia Z	
	Xperia Z1	
	Xperia Z Ultra	
Toshiba	Thrive	
UMI	Cross C1	
Wiko	Cink King	
Xiaomi	Mi-2	
	Mi-2S	
ZTE	V987	

List of Android non-compatible devices.

Note: almost all cheap China or Rockchip-based tablets do not work!

Manufacturer	Model	Notes
Acer	Gallant Duo	No USB host mode
	Iconia B1	No USB host mode
	Iconia Tab A100	No USB host mode
Ainol	Novo 7 elf II	
Alcatel	OT 995	
Asus	MemoPad 7 HD	
BQ	Edison	Probably all models
Cube	U9GT2	Probably all Rockchip-based tablets do not work
Flytouch	9	
Freelander	PD90	Probably all Rockchip-based tablets do not work
Google	Droid 1	
	Droid 3	
HTC	Rebound	
	Sensation 4g	
Huawei	MediaPad	
iOcean	x7	
Irulu		
LG/Google	Nexus 4	No USB host mode, but ziddey franco kernel patch with the AOKP rom can activate it
Median	Life Tab e10310	
Motorola	Droid Bionic	No USB host mode
	Droid Razr M	No USB host mode
Nextbook		
Odys	Tablet PC 4	
Omega	7"	Probably all
Pipo	U3	Rockchip based
Prestigio	all??	
Samsung	Captivate Glide	No USB host mode
	Galaxy Note 1	
	Galaxy Reverb	No USB host mode
	Galaxy S	SGS-T959
	Galaxy S1	No USB host mode
	Galaxy S2	No USB host mode
	Galaxy S3 mini	No USB host mode
	Galaxy S4 mini	No USB host mode
	Galaxy Tab 2	Heavy glitching (OMAP processor). Works perfectly however with Blue Snowball mic...
	Galaxy Tab 3 7"	No USB host mode
Galaxy Young		
Sanei	N86	
Sony	Xperia J	No USB host mode?
Sumvision	Cyclone voyager	
Toshiba	AT200	Heavy glitching (OMAP processor)
Yarvik	All?	